



# ACTIMO® EVOLUTION

High-End Premium Seat with  
Electronical Weight Adjustment



Your GRAMMER  
Distributor:



Unit 1 Forward Park, Sheene Road, Beaumont Leys, Leicester, LE4 1BF  
Tel: 0116 216 9910 | [info@grammer.co.uk](mailto:info@grammer.co.uk) | [www.grammer.co.uk](http://www.grammer.co.uk)



# TECHNICAL DATA

## ACTIMO® EVOLUTION

The Actimo Evolution construction machine seat boasts a deluxe package of comfort-enhancing features. Thanks to electronic weight adjustment, the seat fully automatically sets itself to the operator's weight so the seat can unfold its full potential by optimally utilizing the available suspension travel – thus delivering even greater ergonomics and safety. Active seat climate control removes body moisture so the user will never again have to sit at the wheel in a pool of sweat. On cold days, the integrated seat heating ensures a pleasant temperature.

**Features**    ● Standard    ○ Optional



Pneumatic Suspension



Low-Frequency Suspension



Pneumatic Lumbar Support



Adjustable Shock Absorber



Automatic Positioning System



Electronic Weight Adjustment



Fore/Aft Isolator





Active Climate System

	ACTIMO® EVOLUTION
<b>Article no. fabric</b>	
<b>Compressor 12 V</b>	1294584
<b>Compressor 24 V</b>	1294588
① <b>Document box</b>	●
<b>APS (Automatic positioning system)</b>	●
<b>Armrests, height-adjustable and foldable</b>	
② 80 x 380 mm, adjustable angle, with fabric cover	●
③ <b>Shock absorber adjustable</b>	●
<b>Suspension</b>	
Pneumatic suspension with compressor	●
Low-frequency suspension	●
<b>Suspension stroke 100 mm</b>	●
<b>Weight adjustment 50 - 130 kg, electronic</b>	●

	ACTIMO® EVOLUTION
<b>Height adjustment</b>	
④ 80 mm infinite (air-assisted)	●
⑤ <b>Climate system active</b>	●
⑥ <b>Headrest</b>	●
⑦ <b>Fore/aft adjustment 210 mm</b>	●
<b>Fore/aft isolator</b>	●
⑧ <b>Lumbar support, pneumatic</b>	●
⑨ <b>Adjustable backrest angle</b>	●
⑩ <b>Restraint system</b>	●
<b>Seat cushion width</b>	550 mm
⑪ <b>Seat heating</b>	●
⑫ <b>Adjustable seat cushion depth and angle</b>	●
<b>Operator presence switch (OPS)</b>	●

### Measurements (installation dimensions)



All dimensions in mm.  
Subject to technical changes.